


# SPARE PARTS CATALOGUE



## Samba XXL



## Samba XXL

### Cockpit and Fuselage

#### Electric parts

SL-090	12V socket
SL-091	KS-4 switch
SL-092	KS-6 switch
SL-110	FUSE
SL-111	Circuit breaker
SL-112	Switch (fuse)
SL-113	Button Push To Talk

#### Others

S-093	Gas strut canopy XXL (1pcs)
S-095	Seat cover (for 2 seats)
SL-099	Seat belts (set for aircraft)
S-096	Instrument panel (4 panels)
SL-100	Handle of the control stick
S-091	Ventilate window XXL (1pcs)
S-092	Complete canopy (green) XXL with painted frame
SL-093	Fuel indicator

SL-200	Logbook
--------	---------



#### Fuselage

S-121	RS cover XXL
S-122	Tow hook lever
S-129	Tow hook TOST

Section cockpit – pictures page 1/2



Section cockpit – pictures page 2/2



## Samba XXL

### Wing and Stabilizer

#### Fuel tank

SL-036	Fuel tank float
SL-037	Fuel tank float - sealing
SL-039	Fuel tank key
SL-040	Drain valve
SL-041	Drain valve sealing
SL-045	Tank cap





#### Wings

SL-038	Winglets "T" key
S-040	Set of electric flaps control (actuator+pushrods)
S-041	Shark winglet Samba XXL - paint finished (1pcs)
SL-042	Plexi montage hole cover (1pcs)
S-045	Main wing pin
S-044	Main wing pin safety pin
S-046	Pitot tube XXL - white
S-047	Stickers "DON'T STEP" 2pcs

#### Stabilizer

S-150	Electric trim servo
S-151	Trim indicator
S-152	Trim switch
S-153	Trim pushrod
SL-201	Stab screw
SL-202	Stab screw safety pin

Section wings - pictures



## SAMBA XXL

### Landing gear

#### Front leg

S-005	Front wheel fork XXL - paint finished
S-001	Gas strut 900N
S-222	Front leg- O-ring
S-223	Front leg- spring
S-007	Front wheel pushrod (1pcs)
S-003	Front wheel pushrod adjustable (1pcs)
S-004	Front wheel lever XXL
S-006	Front wheel axle XXL
SL-010	Front wheel tyre
SL-009	Front wheel rim
SL-008	Front wheel tube





#### Main landing gear

S-002	Set of undercarriage legs Samba XXL L+R
S-013	Main wheel cover (1pcs)
S-016	Wheel axle nut
S-019	Wheel axle
S-020	Tyre 15x6 Cheng-Shing
S-021	Tyre 15x6 Goodyear
S-012	Tyre 12x4 Cheng-Shing
S-022	Tyre 14x4
S-023	Tube 14x4
S-024	Tube 15x6 Cheng-Shing
S-025	Tube 15x6 Goodyear
S-008	Tube 12x4 Cheng-Shing

#### Braking system

S-015	Brake pads (set 4pcs)
S-017	Brake disc 14x4
S-027	Brake hose holder
SL-028	Brake wheel unit
SL-029	Main brake cylinder - on stick (Čaja)
SL-033	Bleed screw 14x4
SL-030	Screwing ("T" part with elbow)
SL-032	Hose 4x1 - 1m

Section landing gear - pictures





## Samba XXL

### Engine parts

#### Laminated parts

S-063	Upper XXL engine cowl
S-064	Bottom XXL engine cowl

#### Hoses

SL-075	Oil cooler hose - 1m
SL-076	Water cooler hose- 1m
SL-060	Fuel hose - 1m
S-060	Heating hose - 1m

#### Filters

SL-062	Air filter
SL-069	Oil filter Rotax
SL-082	Fuel filter

#### Other engine parts

SL-064	Engine silentblock
SL-065	Engine silentblock - washer
SL-067	Switch box
S-062	Choke pushrod
S-061	Choke lever
SL-068	Heating pushrod
SL-070	Spark plug Rotax (80hp)
SL-071	Spark plug Rotax (100hp)
SL-072	Oil 10W40 - 1l
SL-079	Oil cooler (80hp)
SL-080	Oil cooler (100hp)
S-066	3 way fuel valve Andair
SL-078	Water cooler
SL-083	Water cooler silentblock
S-224	Exhaust system
S-225	Heating

SL-221	Spinner of the propeller
SL-222	Bottom part of the spinner

Section engine - pictures

